

**TOYOTA** FJA300

**HEAT  
EXCHANGER  
FAN KIT**

  FOLLOW OUR SOCIALS



UP TO  
**60% DROP**  
IN INTAKE TEMPS

**Just Autos**

(07) 5476 0066 [www.justdieselperformance.com.au](http://www.justdieselperformance.com.au)  
Nambour, Sunshine Coast - 11 Windsor Rd, Nambour QLD 4560

D I E S E L P E R F O R M A N C E & D Y N O T U N I N G S P E C I A L I S T

## Part Number - HEFU-FJA300

### Minimum Tooling Required

- > 4mm Hex Key
- > Flat Screw Driver
- > 3/8 Drive 10mm Socket
- > 3/8 Drive Ratchet
- > Metal Cut Off Grinder
- > Personal Protective Equipment

### Heat Exchanger Fan Kit Contents

- > Fan Assembly
- > Fan Bracket
- > 4mm Hex Bolts
- > Flat Washers
- > Split Washers
- > Spacer




- Disconnect factory electrical connector
- Remove existing OEM Fan assembly from vehicle



\*\*\*\*\* Continue To Page 6 Of Heat Exchanger Manual\*\*\*\*\*

➤ Remove bumper air dam mounting bolts




\*\*\*\* Continue To Page 8 Of Heat Exchanger Manual\*\*\*\*

- Install supplied fasteners to mount fan to Heat Exchanger core  
*Connect OEM electrical connector to factory harness*



- Connect OEM electrical connector to factory harness



\*\*\*\*\* Continue To Page 10 Of Heat Exchanger Manual\*\*\*\*\*

- Apply nut to previously removed bolts  
Using grinder with thin cut off disk - Remove excess thread. **5mm approx.**  
*Safety note - Use personal protective equipment*  
Reinstall bolts once length is adjusted



- Apply spacer to allow for correct clearance of upright support



\*\*\*\*\* Continue To Page 17 Of Heat Exchanger Manual\*\*\*\*\*