



FOLLOW OUR SOCIALS

EASY LOCK INFORMATION

> Lock up speed / Unlock speed*

- Low Speed Lock - 40km/h
- Low Speed Unlock - 35km/h
- Auto/High Speed Lock - 94km/h
- Auto/High Speed Unlock - 84km/h

> How do I switch on my High Speed

High Speed/Auto Lock up is a set function & will automatically engage, It does not require a button to be pushed. The High Speed/Auto Lock up will engage at the set speed.

> How do I switch on my Low Speed

Low speed Lock up is engaged using the vehicle 2nd Start button. When operating Low Speed lock up Just Autos recommends using Sport shift to manually select gear.

**** If manual selection is not carried out a shudder may be noticed at low speeds****

> Will 2nd Start Button still work as it did previously?

2nd Start button will now be used to engage and disengage vehicle low speed lock up. Button will not work as previously

> How do I know Easy Lock up is on?

High Speed/Auto lock up is programmed to automatically engage at the set speed, user input is not required to enable or disable this function

"Lock up will engage automatically at the set speed"


Low Speed lock up once depressed will illuminate 2nd start light on the dash

"Lock up will engage at set speed"

> How does this benefit my vehicle?

Lock up operation will reduce transmission temperatures and can aid improve fuel economy and help with general drivability of the vehicle

Low Speed



**** Lock up speeds may vary depending on tyre sizes & diff ratios ****

Just Autos

D I E S E L P E R F O R M A N C E & D Y N O T U N I N G S P E C I A L I S T S

(07) 5476 0066 www.justautos.au

Nambour, Sunshine Coast - 11 Windsor Rd, Nambour QLD 4560

UP TO
50% DROP
IN TRANS TEMPS